

料罐，容器和料仓称重

称重传感器选型时的计算方式:

3 个支腿:称重传感器的量程 $\geq 1.3 \times$ 总载荷 / 支腿数量

4 个支腿:称重传感器的量程 $\geq 1.5 \times$ 总载荷 / 支腿数量

称重传感器的选择指南和推荐的安装模块:

每个支腿的最大载荷	称重传感器的型号	支撑模式	
5-10-20-30-50-75-100-150-200-250-300-500kg	Mod. 300	安装底板和防震块	
		料罐支腿带防倾翻装置	
300-500-750-1000-1500-2000kg 3000-5000kg	Mod. 350	料罐支腿带防倾翻装置	
		安装底板和防震块	
2.5-5-10t 20-30t	Mod.420	料仓的安装模块带有防倾翻保护装置	
5-10-20t 30-50t 75-100t	Mod. 460	料仓的安装模块带有防倾翻保护装置	
15-20-25-30-40t 60t 100-200t 400t 600t	Mod. 740	料仓的安装模块带有防倾翻保护装置	
接线盒 89053，密封外壳，可接 4 传感器			