



SILENT-BLOCK SYSTEM & BASE PLATE

Acc. 30904-30903/30903i (5...50kg)

Acc. 30905-30903/30903i (75...300kg)

Acc. 30906-30903/30903i (500kg)

BASIC MOUNTING INSTRUCTIONS

(Rev. 1 – 07/14)



1. Material received with the mounting kit.



Acc. 30904 (5...50kg), Acc. 30905 (75...300kg), Acc. 30906 (500kg)




Acc. 30903/30903i

2. Place the accessory on its installation position and fix it to the foundation. Ensure that the base is firm, horizontal and leveled.
3. Mount the Load Cell and the Load Bolt on the lower plate. Keep in mind the arrow sense of the Load Cell.




Base Plate + Load Cell + Load Bolt



Arrow sense of the Load Cell

4. Perform the mounting of the spacer on the Load Cell; then mount the Silent-Block.



Spacer mounting



Silent-Block mounting